NOTE: This guide is for accessing the raspberry pi using a MAC. The IP addresses, hostnames, and passwords can be used as a starting block to access the pi using a Windows computer.

#### SSH into pis

- 1. Open Terminal
- 2. Two ways to access (Use Table 1)
  - a. Ethernet Adapter
    - i. Type "ssh pi@IP Address of the pi"
  - b. Micro USB
    - i. Type "ssh pi@Hostname.local"
- 3. Enter password from table 1

	IP Address	Hostname	Password
В0	192.168.1.100	HABIP-B0	raspberry
B1	192.168.1.110	HABIP-B1	raspberry
B2	192.168.1.120	HABIP-B2	raspberry
В3	192.168.1.130	HABIP-B3	raspberry
DTV	192.168.1.15	HABIP-DTV	splintercell
Comms	Non-Static	raspberrypi	raspberry

Table 1 – Raspberry Pi Information

## Working on DACQs pis (B0-B3)

- 1. End the data acquisition python scripts
  - a. Once in the pi type "cd habip"
    - i. This will get you into the habip folder
  - b. Type "ps -aux | grep python"
    - i. This will show all python scripts that are running
  - c. Type "sudo -9 kill <PIDs>
    - i. The previous command will show the PID (Process ID #) of the python scripts.
    - ii. You can kill multiple scripts by adding a space between their PID#
  - d. Rather quickly type "python wdt\_pet.py"
    - i. This will activate the script that "pets" the watchdog to keep the pi from resetting.
      - 1. The pi resets whenever the i2c data logging script is not running.
  - e. You must open another instance/shell for this pi to work on it since the wdt\_pet.py script needs to stay running in order to keep from resetting the pi.

#### Deleting Data from the DACQs pi

- 1. Once in the pi go to habip folder by typing "cd habip"
- 2. Type "bash remove\_all\_data.sh"
  - a. This will remove all the logs, photos, videos, and data from the pi
- 3. The pi is now ready for flight/testing

### Retrieving data from the pis

I used SCP but with dome searching you can probably find other methods. Just use whatever works best for you.

## **Script Location on the pis**

**NOTE:** Use /home/pi before any of these paths using SCP or any path designation in scripts

# DACQs pis

Photo and Video Logging - /habip/photo\_video\_sw/

The script (log\_photo\_video.py) and the photos, videos, and logs folders for photo and video logging can be found in this folder.

UART Monitor - /habip/uart\_monitor/

Data Logging - /habip/sensors\_sw/

Both the i2c sensors and the wire1 data folders can be found here. The i2c and wire both have there own script.

#### DTV pi

All the scripts are in the location /ts\_tools/

The script that controls the BladeRF is "BladeRF.py", the script for switching between the camera feeds is "Switching.py", and the script for testing one individual Pi for DTV is "PiServer.py".

#### Comms pi

Trying to figure this pi out was a nightmare. There was no clear organization of this pi, its folders, and its scripts. I would recommend rewriting and reorganizing this pi if this same system will be kept in the future.